

Nama Pencawang : PE RESIDENSI LESTARI 4
Functional Location : WKLS/PCE/J01896
Kawasan : WKLS
Koordinat :
Jenis Pencawang :
Jenis Comms : DSR
CAASDU : 1261
DTU ID :
SIM CARD No :
IP Address :

DATE
BCE : 2026-02-05 Functional Test (Plant - RCB)
RCB : 2026-02-05 Local Test (Plant - RCB - RTU)
Work : Integration test (RCB - RTU - Master)
Comms : Commissioning Test (Plant - RTU/FTU - Master)

RTU/FTU Brand : DONG FANG
RTU/FTU Serial No. : VCB BJ0082
RTU/FTU No. : TNB131/2024
RTU / FTU Protocol : IEC101

SIGNAL	FEEDER												DETAILS RTU			
	59112	59114	59113	59115								RTU/FTU	BCE 1	BCE 2	SAT Form	: Ada
															Master sheet	: Ada
															As Built Drawing	: Ada
INDICATION													DETAILS PIW			
CB OPEN	✓	✓	✓	✓											No. PIW	TNB131/2024
CB CLOSE	✓	✓	✓	✓											Wiring List	: ADA
PROT. ALARM																
SUPER/REMOTE	✓	✓	✓	✓											As Built Drawing	: ADA
OVERCURRENT	✓	✓	✓	✓											RCB Brand	AHM
EARTHFAULT	✓	✓	✓	✓											RCB No.	TNB1628/2022
IRF	✓	✓	✓	✓											No of RCB	1
EARTH SWITCH	✓	✓	✓	✓											RCB 1 Serial No.	BF250151
EFI OPERATED	✓	✓		✓											RCB 2 Serial No.	
C.E.S												✓			RCB 3 Serial No.	
CHARGER ALARM													✓	✓	BCE 1 Brand	BERKAT INSAF
AC FAIL													✓		BCE 1 No.	TNB338/2024
DC LV															BCE 1 Serial No.	B22964
TCS	✓	✓	✓	✓												
ANALOG													No. Feeder	Feeder Name		
CT RATIO	600 / 5	600 / 5	300 / 5	600 / 5											59112	PPU TASIK PERMAISURI CB5
														59114	PE KLW BANDAR TUN RAZAK	
														59113	TX 1000KVA	
AMP 0%	✓	✓	✓	✓										59115	PE RESIDENSI LESTARI 2	
AMP 50%	✓	✓	✓	✓												
AMP 100%	✓	✓	✓	✓												
CONTROL																
CB CTRL OPEN	✓	✓	✓	✓									✓			
CB CTRL CLOSE	✓	✓	✓	✓									✓			
EFI RESET	✓	✓		✓												

PIC Tapak : MOHD TARMIZI ALIAS

PIC MASTER :

: